

Figure - Bug #117958

测试 Test-IT # 111062 (New): V3.0功能测试

测试 Test-IT # 111069 (New): AF-V3.0--Launcher/SystemUI-小窗模式入口

【IOVDEV-28209】【IOVDEV-28213】【小窗模式】部分应用小窗模式下执行返回手势，直接返回桌面，而不是返回上一级页面

2023-05-16 15:33 - CD TEST-方永红

Status:	CLOSED	Start date:	2023-05-16
Priority:	Normal	Due date:	
Assignee:	CDTS_TEST 王成	% Done:	0%
Category:	依赖客户及其供应商解决	Estimated time:	0.00 hour
Target version:		Found Version:	FlatBuild_HH_MCE_FSE.M.R.user.01.00.0100
Need_Info:	TEST	Degrated:	--
Resolution:	--	Verified Version:	
Severity:	Normal	Fixed Version:	
Reproducibility:	Every time	Root cause:	直接返回到桌面是因为这些应用都只启动了一个界面
Test Type:	ST		
Description			
【测试步骤】			
1、打开喜马拉雅or酷狗音乐			
2、进入二级或者三级页面			
3、屏幕左侧执行返回手势			
【预期结果】			
3、返回上一级页面			
【实际结果】			
3、直接返回桌面			

History

- #1 - 2023-05-16 16:44 - CD FW-鲁凯峰
- File 全屏.mp4 added

- Category changed from 窗口定制to 依赖客户及其供应商解决

- Status changed from New to NEED_INFO

- Assignee changed from CD FW-鲁凯峰to CDTS_TEST 王成

- Need_Info changed from -- to TEST

- Root cause set to 直接返回到桌面是因为这些应用都只启动了一个界面,跳转都只是替换内部的视图,没有新起一个界面,所以就直接返回到桌面了

这个是正常的逻辑，如果当前只有一个界面的话,触发返回就是销毁当前应用,返回到上一个应用.

直接返回到桌面是因为这些应用都只启动了一个界面,跳转都只是替换内部的视图,没有新起一个界面,所以就直接返回到桌面了

比如说酷狗,启动后的界面MediaActivity, 点击立即参与按钮后,它的界面还是MediaActivity,它并没有创建一个新的界面来显示立即参与的内容
所以触发返回后,把当前的MediaActivity销毁掉就会直接返回到桌面

```
05-10 23:17:18.589 1027 5109 I ActivityTaskManager: START u0 {act=android.intent.action.MAIN cat=[android.intent.category.LAUNCHER] flg=0x10200000  
cmp=com.kugou.android/.app.MediaActivity (has extras)} from uid 10100
```

全屏模式下相同的操作也是一样的界面

系统侧这边无法修改这个逻辑

#2 - 2023-05-17 16:06 - CDTS_TEST 王成
- Status changed from NEED_INFO to RESOLVED

#3 - 2023-05-17 16:06 - CDTS_TEST 王成
- Status changed from RESOLVED to VERIFIED

#4 - 2023-05-17 16:07 - CDTS_TEST 王成
- Status changed from VERIFIED to CLOSED

Files				
Phone-STS40X190078 2023-05-16 15-32-24.mp4	12.9 MB	2023-05-16	CD TEST-方永红	
全屏.mp4	37.1 MB	2023-05-16	CD FW-鲁凯峰	